

Immobiliser status

Learn EMS code

Immobiliser status

Correct EMS code received

Note that immobiliser must be disarmed in order to read status.

Back

Remove the keys before closing the doors to avoid locking the keys inside the vehicle.

Back

Next

Alarm must not be immobilised

Back

Next